LUND UNIVERSITY

Measurement Techniques

JUAN NEGREIRA



M.Sc. Civil Engineering / TeknL
PhD candidate
Department of Construction Sciences
Division of Engineering Acoustics

Measurement Techniques

JUAN NEGREIRA

30th January 2014

Outline

- Introduction
- Signals
- Exitation Sources
- Measurement Devices
- Errors in Measurements
- Examples
- Conclusions

Introduction

Introduction





LUND UNIVERSITY

Introduction

- Paradigm of natural sciences



  - Theory: explanained and generalised experimental results
  - Prediction: use theory to predict consequences
  - Experiment: observation / measurement of phenomena

Introduction

Eisenhart [1876-1965]: "*To measure is to assign numerical values to concepts of physical quantities to symbolise the relations which exist between them regarding special properties*"

Introduction



- Experimental process to acquire new knowledge of a "product"
- Process: planned actions for quantitative comparison of a measurand with an unit
- Measurand: physical quantity to be measured
- Measurement equipment: software, standards, aparatus…

LUND UNIVERSITY

Signals

Signals

- Acquisition: voltage-time
  - Unequivocally related to the measurand



+



- Noise: changes the smooth signal to a "jagged" curve



- Signal to noise ratio (SNR)
  - SNR>1 means Signal>Noise
  - Filtering

$$SNR = \frac{P_{signal}}{P_{noise}}$$

$$SNR_{dB} = 10\log_{10}\frac{P_{signal}}{P_{noise}}$$

LUND UNIVERSITY

Getting ready for the analysis

- To get the signal into a computer, one needs to digitalise it
- Digitalise (also digitise): conversion from analogue signal to a stream of discrete values (numbers)
- Δt between two consecutive values: given by sampling frequency



An Analog, continuous-time signal   An Analog, discrete-time signal

Sampling Frequency



- The red dots (samples) do not truly represent the signal
- The sampling frequency must be twice the higher frequency in the signal

NYQUIST-SHANNON CRITERIA

Nyquist-Shannon Sampling Criteria

Let *x(t)* be a continuous-time signal and *X(f)* its FT

$$X(f) \overset{Def}{=} \int_{-\infty}^{+\infty} x(t) e^{i2\pi ft} dt$$

x(t) is said to be bandlimited to a one-sided baseband bandwidth, *B*, if:

$$X(f) = 0 \qquad \forall \qquad |f| > B$$

The the sufficient condition for "exact" reconstructability from samples at uniform sample rate is:

$$f_s > 2B \Leftrightarrow B < \frac{f_s}{2} \qquad ; \qquad T \overset{Def}{=} \frac{1}{f_s}$$

2B is called the Nyquist rate and it is a property of the band-limited signal, while ($f_s/2$) is called the Nyquist frequency and is a property of the sampling system

LUND UNIVERSITY

Aliasing

- If Nyquist-Shannon criteria is not fulfilled (bad sampling)
  - Two different continuous signals become indistinguishable



- Example: Helicopter: Stroboscopic effect
- Example: Image aliasing (Sampling / Pixel density wrong)



How to analyse the data?

- Waveform: amplitude as a function of time
- Spectrum: frequencies contained in the signal
- Leap between domains: FT
- In practice, software apply FFT



(a) Time domain.



(b) Frequency domain.

LUND UNIVERSITY

FFT example (Matlab)

```
%Juan Negreira; May 2011
%Calculates the discrete fourier transform of the timedomain signal y(t)
%Y:amplitude of the frequency components
%f:frequencies[Hz]
%Only the unique points are returned ie. f lies in 0 <= f <= Fs/2

%% Introducing the time signal
dt=1/100;
et=4;
xData=0:dt:et;
yData=3*sin(4*2*pi*xData);
%% Calculating the FFT
%Number of points in input data
NFFT=length(yData);
%Nyquist frequency
Fn=1/(xData(2)-xData(1))/2;
%Absolute value of the FRF
FFTY=abs(fft(yData));
NumUniquePts=ceil((NFFT+1)/2);
% fft symmetric, throw away second half
FFTY=FFTY(1:NumUniquePts);
% Take magnitude of Y
Yfft=abs(FFTY);
% Multiply by 2 to take into account the fact that we
% threw out second half of FFTY above
Yfft=Yfft*2;
% Account for endpoint uniqueness
Yfft(1)=Yfft(1)/2;
% We know NFFT is even
Yfft(length(Yfft))=Yfft(length(Yfft))/2;
% Scale the FFT so that it is not a function of the length of y.
Yfft=Yfft/length(yData);
%Frequencies
freq=(0:NumUniquePts-1)*2*Fn/NFFT;
%% Plotting time signal and FFT
subplot(2,1,1)
plot(xData,yData); grid on
axis([0 et -8 8])
xlabel('Time [s]'); ylabel('Amplitude')
subplot(2,1,2)
plot(freq, Yfft);grid on
xlabel('Frequency [Hz]'); ylabel('Amplitude')
```



FFT example (Matlab)



FFT example (Matlab)



LUND UNIVERSITY

Resonance

- Resonance (def.):
  - Tendency to oscillate at a greater amplitude at some frequencies
- Depends on:
  - Mass
  - Stiffness
  - Damping
- Examples:
  - Earthquake design
  - Tacoma Bridge
  - Cup
  - Plate (mode shapes)



Excitation Sources

Excitation Sources (Floor Vibrations)

- Standardised
  - Tapping machine
  - Rubber tire
- Non-Standardised
  - Shaker
  - Japanese Ball
  - Impact Hammer
  - Human Walking

LUND UNIVERSITY

Excitation Sources (Acoustics)

- Standardised
  - Loudspeakers
- Non-Standardised
  - Cap-gun
  - Baby-crying
  - Impulse

Measurement Devices

Sensors and Transducers

- Transducers: detection
- Sensors: detect and communicate
  - Parameters:
    - » Sensitivity: “electrical output / mechanical input”, [mV/ms^{-2}]
    - » Frequency response: sensitivity over whole spectra
    - » Phase response: time delay between input and output
    - » Resolution: smallest input increment reliably detected
    - » Dynamic Range: output proportional to input
    - » Saturation: maximum output capability
    - » Weight < 0.1 x weight specimen to be measured
    - » Environmental characteristics: temperature, humidity…
    - » Repeatability / Reproducibility
    - » Eccentricity

Calibration

- What is it?
  - Comparison between the value indicated in a device and a reference known value

- Why calibrate?
  - Repeatability
  - Transference
  - Equipment exchange
  - Fulfillment of quality standards

Calibration

- Examples:
  - Sound level meter:

  - Accelerometers:

LUND UNIVERSITY

Microphones

- Acoustical-to-electric transducer (sound → electric signal)
- Scalar pressure sensors with an omnidirectional response

Microphones

- Requirements:
  - Good acoustic and electric performance
  - Minor influence from the environment
  - High stability of sensitivity and frequency response
  - High suitability for measurement
  - Comprehensive specifications and performance description.





LUND UNIVERSITY

Accelerometers

- Mechanical, piezoelectric, hall effect, capacitive...









LUND UNIVERSITY

Others

- Gyroscopes
  - Measure or maintaining orientation
  - Based on conservation of angular momentum

- LVDT Sensors
  - Linear Variable Differential Transformers
  - Output voltage proportional to the displacement of the core





LUND UNIVERSITY

Others

- Pressure Sensors
  - Output voltage proportional to the pressure



- Interferometers
  - Output voltage if obstacle detected



- Velocity Pickups
  - Voltage proportional to the relative velocity between elements
- SmartPhones
  - Different sensors

LUND UNIVERSITY

In-situ Vibratory Measurements





Video

In-situ Vibratory Measurements





Video

Errors in Measurements

Introduction

- Ideal measurements: no errors
- Real ones always do
- Clear defined processes to identify every source of error
- Measurement system errors can only be defined in relation to the solution of a real specific measurement task



LUND UNIVERSITY

VoIA

- Value of Information Analysis (VoIA)
  - How much do I want to "pay" for my information / output?



LUND UNIVERSITY

VoIA

- Value of Information Analysis (VoIA)
  - How much do I want to “pay” for my information/output?

1.234 m

1.234 m ± 0.017 m

2 000 000 €

?

LUND UNIVERSITY

The issue of scale...

Errors in Measurements

- Before the measurement:
  - Uncertainty
  - Reliability / Confidence
  - Risk
  - Probability



- After the measurement:
  - Error: $\Delta x = x_{real} - x_{measured}$

NOTE: the concept of error presumes a knowledge of the correct value and it's therefore an abstraction

LUND UNIVERSITY

Quality of Measurements

- Lack of systematic deviation from a true value: accuracy
- Bias: average deviation from a true value
- Lack of scatter: precision
  - Repeatability (variability when measuring by 1 person)
  - Reproducibility (variability caused by changing operator)



Accuracy / Bias / Precision



Accuracy = Bias + Precision

a) high bias + low precision = low accuracy

b) low bias + low precision = low accuracy

c) high bias + high precision = low accuracy

d) low bias + high precision = high accuracy

Error “Chain”

- Measurement system type. Common errors:
  - Input error
  - Sensor error
  - Signal Transmission error 1
  - Transducer error
  - Signal Transmission error 2
  - Converter error
  - Signal Transmission error 3
  - Computer error
  - Signal Transmission error 4
  - Indication error



Figure 1. Measurement chain.

Types of Errors

- Systematic error (bias)
  - Permanent deflection in same direction from true value
  - It can be corrected
  - Types:
    - » Lack of gauge resolution
    - » Lack of linearity
    - » Drift
    - » Hysteresis



Types of Errors

- Gross errors
  - Human mistakes

$$X_{true} = X_{measured} + e_{syst} + e_{random}$$

- Random error
  - Remains after correct gross and systematic errors
    - » It cannot be corrected
  - Short-term scattering of values around a mean value
  - Varies in an unpredictable way
  - Expressed by statistical methods
  - Reasons
    - » Lack of equipment sensitivity
    - » Noise
    - » Imprecise definition

LUND UNIVERSITY

Examples of Errors

- Wire error







Examples of Errors

- Music and external impact





LUND UNIVERSITY

Examples of Errors

- Step motor (2 Hz / 4.5 Hz)
  - Harmonic signal?







More Examples of Real Measurements

Prefabricated Wooden Buildings

- Timber volume element (TVE)-based building



- Method (numerical prediction tools):
  - Calibration FE model with in-situ measurements
  - Modify features in the model

FE Model TVE-based building



Calibration (Preliminary Results)

- Measurements





- Simulations





LUND UNIVERSITY

T-junctions









LUND UNIVERSITY

Wall-Floor Building Element





LUND UNIVERSITY

Psycho-Vibrations

- Subjective: 31 subjects / 5 floors
  - Walking
  - Seated
- Objective measurements

- 310 data files (subjective)
- 30 data files (objective)
- Always planned actions!!

LUND UNIVERSITY

Flanking Transmission





Conclusions

- To measure: acquire knowledge of a new product
  - Analyses prior to measurements
  - Measurement plan based on analyses and purpose
- Signals: frequency and time domain
  - Nyquist-Shannon criteria
  - Resonance
- Excitation sources
- Measurement devices
- Errors
  - Measurements: accompanied by a quality statement
- Document the process (pictures, notes…)

Thank you for your attention!

Juan.Negreira@construction.lth.se

LUND UNIVERSITY